



AV Cart 45





IMPORTANT INFORMATION


Please ensure this product is installed as per these installation instructions.

- The manufacturer accepts no responsibility for incorrect installation.
- Failure to mount this product correctly may cause serious injury/death during or following installation.
- This product should only be installed by professional installers of good mechanical aptitude, who fully understand these
- instructions and the consequences of incorrect installation. Do not over tighten screws.
- Two person installation is recommended. Product not suitable for use outdoors.
- After installation is complete check to verify that TV Cart is secure and safe for use.
- Curved monitors, deep devices (such as all-in-one PCs), VESA mounted accessories (such as mini PC brackets and mounts), and offset VESA locations exert additional leverage that can exceed the capacity of the mount even though the monitor weight may be within the stated range. Please contact Atdec if you would like further information. WARNING! Death or serious injury may occur when children climb on audio and/or video equipment furniture. A remote control
- or toys placed on the cart may encourage a child to climb on the cart and as a result the cart may tip over on to the child.


WARNING! ! CART CAN TIP OVER RESULTING IN RISK OF INJURY! ! DO NOT ALLOW CHILDREN UNDER 16 TO PLAY WITH OR MOVE CART ! MOVE CART SLOWLY



1. Install the castors



2. Attach column to the base




3. Set column height


3.1 Use thumb or finger to depress the spring button located in the cable window on the lower right column. At the same time use other hand to twist then pull upper column upward until your desired height. Twist motion is to ensure spring button doesn't engage unintentionally.

Twist upper column back toward the plunger holes and engage the spring button into the plunger hole. Ensure spring button pops out as shown in Fig-2.


3.2 Repeat step 1 on left column.




4. Assemble and install shelf




5. Attach mounting plate




6. Attach VESA brackets to display



7. Mount display




8. Cable routing options



9. Adjust display height

9.1 Two people are required to change display height. Display must be removed prior to adjusting height.



9.2 Person "A" holds the top section of the telescopic column. Person "B" depresses left and right spring buttons on column by using thumbs, so that person "A" can move top of column down or up to desired height.

Take care to ensure spring buttons are not pressed further than necessary to disengage from column.

9.3 When height is determined, let spring button set into plunger holes. Ensure both spring buttons have popped out.

Maintenance

- Tighten fasteners and check the cart is secure and safe to use at regular intervals (at least every three months.)
- Please contact your distributor if you have any questions.



No portion of this document or any artwork contained herein should be reproduced in any way without the express written consent of Atdec Pty Ltd. Due to continuing product development, the manufacturer reserves the right to alter specifications without notice. ©20211008